



NT/TE settings port X	
JP1-2 Set all jumpers to the left to select NT mode for port X	Set all jumpers to the right to select TE mode for port X
Power feeding port X (only for NT mode)	
JP3-4 Power feeding enabled for port X (PFM required)	Power feeding disabled for port X (factory default)
Power supply configuration	
JP5 Uses 3.3V from the PCI bus (only available in 3.3V PCI slots)	Generates 3.3V out of the 5V from the PCI bus (factory default)

Status LED	
LED	Layer 1 activated Layer 1 deactivated

Termination of S/T interface port X (100Ω)	
SW1-2 Both switches in ON position activates termination for port X	Both switches in OFF position deactivates termination for port X

Card ID switches																																					
Use DIP switches 1 to 3 to set the card ID (very useful for remotely identifying individual cards):																																					
SW3	<table border="1"> <thead> <tr> <th>Card-ID</th> <th>0</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> <th>5</th> <th>6</th> <th>7</th> </tr> </thead> <tbody> <tr> <td>SW3_1</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>SW3_2</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>SW3_3</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>ON</td> <td>ON</td> </tr> </tbody> </table>	Card-ID	0	1	2	3	4	5	6	7	SW3_1	OFF	ON	OFF	ON	OFF	ON	OFF	ON	SW3_2	OFF	OFF	ON	ON	OFF	OFF	ON	ON	SW3_3	OFF	OFF	OFF	OFF	ON	ON	ON	ON
Card-ID	0	1	2	3	4	5	6	7																													
SW3_1	OFF	ON	OFF	ON	OFF	ON	OFF	ON																													
SW3_2	OFF	OFF	ON	ON	OFF	OFF	ON	ON																													
SW3_3	OFF	OFF	OFF	OFF	ON	ON	ON	ON																													

CON1	PCM out
CON2	PCM in
CON3	Onboard PFM connector (available optionally)
Power connector	
CON4	Connector for the external power feeding module to feed S/T interfaces of up to 4 duo- or quadBRI cards (available optionally)
CON5	Watchdog connector out Connect to reset switch on mainboard
CON6	Watchdog connector in Connect to reset switch on PC chassis